




OEM/ODM



KAREEMA

Safe and
reliable switch
socket

Fashion and
contracted switch
socket

COMPANY Profile

After years of development, the company has become a large modern electrical appliance enterprise integrating manufacturing, scientific research, trade and service. The company's products are mainly involved in electriciansProducts, construction electrical appliances, industrial electrical appliances, small household appliances and electrical appliances, produce 9 series of nearly two thousands of products such as wall switches and sockets, and have 800 agents in China, 6,000 sales networks.

In the long-term practice, we have taken the initiative to understand and cultivate the market with advanced concepts and actions, created a new concept of market expansion, and established a nationwide The marketing network has formed a strong brand competitiveness.

The company has strong technical production capacity, has many domestic leading technical production lines, and has more than 20 senior engineers. Our company cooperate with the leading design institutes , the introduction of the world's advanced equipment, supplemented by imported high-quality PC materials and exquisite production technology, manufactures electrical products that are close to life and lead the market.

With strong technical research and development strength and humanized management concepts, the company strives to provide consumers with personalized and high-quality life enjoyment. Thecompany strictly enforces S9001: 2000 international quality management system standards, and pass the national compulsory 3C certification, and strive to provide high-quality products and best services .Improving the visibility and reputation of the company's brand.

German Quality

THE PERFECT COMBINATION OF
QUALITY AND VALUE



RoHS CE

20 year OEM ODM




KAREEMA

The configuration is flexible and vivid, and the ingenious combination of practicality and art makes it easy to enjoy excellent life. Classic, cast in the cycle of fashion, shines with extraordinary charm in the flow of time.

A6 | series


German Quality

Unique large board design, simple and flexible.

The perfect golden ratio without losing the sense of technology, Beneath the fashionable appearance, It is gorgeous and beautiful. The interior exudes the charm of warm elements.

☐ White ☐ Gold ☐ Gray ☐ Black





A6-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch




A6-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



A6-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



A6-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



A6-05
Doorbell Switch




A6-06
MF Switch Socket
With Neon



A6-07
MF Switch Socket
With Neon+2USB




A6-08
MF Switch Socket
With Neon+USB+ Type-C



A6-09
15A Switch Socket With Neon
A6-10
32A Switch Socket With Neon




A6-11
5 pin MF Switch Socket
With Neon



A6-12
13A Switch Socket
With Neon



A6-13
13A Switch Socket
With Neon+2USB



A6-14
13A Switch Socket
With Neon+USB+ Type-C



A6-15
5 pin MF Switch Socket
With Neon+2USB



A6-16
5 pin MF Switch Socket
With Neon+USB+ Type-C



A6-17
13A Socket



A6-18
Four Pole Socket



A6-19
5 pin MF Socket



A6-20
25A switch with neon



A6-21
45A switch with neon



A6-22
20A switch with neon
A6-23
45A switch with neon




A6-24
Germany socket




A6-25
French socket



A6-26
Europe socket



A6-27
Satellite Socket



A6-28
TV Socket



A6-29
TEL Socket
A6-30
Computer Socket



A6-31
TV+ TEL Socket
A6-32
Satellite+Computer Socket



A6-33
Double Computer Socket
A6-34
TV+ Computer Socket




A6-35
Satellite+TV Socket
A6-36
Double TV Socket



A6-37
Dimmer Switch
A6-38
Speed Control Switch




A6-39
Human Body Sensor
Switch




A6-40
25A Junction Box



A6-41
45A Junction Box




A6-42
86 Blank Plate




A6-43
Double 13A Switch Socket
With Neon




A6-44
Double 13A Switch Socket
With Neon+2USB




A6-45
Double 13A Switch Socket
With Neon+USB+ Type-C




A6-46
Double 13A Socket




A6-47
Double MF Switch Socket
With Neon




A6-48
Double MF Switch Socket
With Neon+2USB




A6-49
Double MF Switch Socket
With Neon+USB+ Type-C




A6-50
Cooker Unit




A6-51
Double 5 pin MF Switch Socket
With Neon




A6-52
Double 5 pin MF Switch Socket
With Neon+2USB



A6-53
Double 5 pin MF Switch Socket
With Neon+USB+ Type-C



A6-54
146 Blank Plate



A6-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



A6-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



A6-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



A6-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



A6-05
Doorbell Switch



A6-06
MF Switch Socket
With Neon



A6-07
MF Switch Socket
With Neon+2USB



A6-08
MF Switch Socket
With Neon+USB+ Type-C



A6-09
15A Switch Socket With Neon
A6-10
32A Switch Socket With Neon



A6-11
5 pin MF Switch Socket
With Neon



A6-12
13A Switch Socket
With Neon



A6-13
13A Switch Socket
With Neon+2USB




A6-14
13A Switch Socket
With Neon+USB+ Type-C



A6-15
5 pin MF Switch Socket
With Neon+2USB



A6-16
5 pin MF Switch Socket
With Neon+USB+ Type-C



A6-17
13A Socket



A6-18
Four Pole Socket



A6-19
5 pin MF Socket



A6-20
25A switch with neon



A6-21
45A switch with neon



A6-22
20A switch with neon
A6-23
45A switch with neon



A6-24
Germany socket



A6-25
French socket



A6-26
Europe socket



A6-27
Satellite Socket



A6-28
TV Socket



A6-29
TEL Socket
A6-30
Computer Socket



A6-31
TV+ TEL Socket
A6-32
Satellite+Computer Socket



A6-33
Double Computer Socket
A6-34
TV+ Computer Socket



A6-35
Satellite+TV Socket
A6-36
Double TV Socket



A6-37
Dimmer Switch
A6-38
Speed Control Switch




A6-39
Human Body Sensor
Switch




A6-40
25A Junction Box




A6-41
45A Junction Box



A6-42
86 Blank Plate




A6-43
Double 13A Switch Socket
With Neon




A6-44
Double 13A Switch Socket
With Neon+2USB




A6-45
Double 13A Switch Socket
With Neon+USB+ Type-C



A6-46
Double 13A Socket




A6-47
Double MF Switch Socket
With Neon



A6-48
Double MF Switch Socket
With Neon+2USB




A6-49
Double MF Switch Socket
With Neon+USB+ Type-C



A6-50
Cooker Unit



A6-51
Double 5 pin MF Switch Socket
With Neon



A6-52
Double 5 pin MF Switch Socket
With Neon+2USB



A6-53
Double 5 pin MF Switch Socket
With Neon+USB+ Type-C



A6-54
146 Blank Plate



A6-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



A6-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



A6-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



A6-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



A6-05
Doorbell Switch



A6-06
MF Switch Socket
With Neon



A6-07
MF Switch Socket
With Neon+2USB



A6-08
MF Switch Socket
With Neon+USB+ Type-C



A6-09
15A Switch Socket With Neon
A6-10
32A Switch Socket With Neon



A6-11
5 pin MF Switch Socket
With Neon



A6-12
13A Switch Socket
With Neon



A6-13
13A Switch Socket
With Neon+2USB



A6-14
13A Switch Socket
With Neon+USB+ Type-C



A6-15
5 pin MF Switch Socket
With Neon+2USB



A6-16
5 pin MF Switch Socket
With Neon+USB+ Type-C



A6-17
13A Socket



A6-18
Four Pole Socket



A6-19
5 pin MF Socket



A6-20
25A switch with neon



A6-21
45A switch with neon



A6-22
20A switch with neon
A6-23
45A switch with neon



A6-24
Germany socket



A6-25
French socket



A6-26
Europe socket



A6-27
Satellite Socket



A6-28
TV Socket



A6-29
TEL Socket
A6-30
Computer Socket



A6-31
TV+ TEL Socket
A6-32
Satellite+Computer Socket



A6-33
Double Computer Socket
A6-34
TV+ Computer Socket



A6-35
Satellite+TV Socket
A6-36
Double TV Socket



A6-37
Dimmer Switch
A6-38
Speed Control Switch



A6-39
Human Body Sensor
Switch



A6-40
25A Junction Box



A6-41
45A Junction Box




A6-42
86 Blank Plate



A6-43
Double 13A Switch Socket
With Neon



A6-44
Double 13A Switch Socket
With Neon+2USB



A6-45
Double 13A Switch Socket
With Neon+USB+ Type-C



A6-46
Double 13A Socket



A6-47
Double MF Switch Socket
With Neon



A6-48
Double MF Switch Socket
With Neon+2USB



A6-49
Double MF Switch Socket
With Neon+USB+ Type-C




A6-50
Cooker Unit



A6-51
Double 5 pin MF Switch Socket
With Neon



A6-52
Double 5 pin MF Switch Socket
With Neon+2USB



A6-53
Double 5 pin MF Switch Socket
With Neon+USB+ Type-C



A6-54
146 Blank Plate

				
A6-01 1 Gang 1 Way Switch	A6-02 2 Gang 1 Way Switch	A6-03 3 Gang 1 Way Switch	A6-04 4 Gang 1 Way Switch	A6-05 Doorbell Switch
				
A6-06 MF Switch Socket With Neon	A6-07 MF Switch Socket With Neon+2USB	A6-08 MF Switch Socket With Neon+USB+ Type-C	A6-09 15A Switch Socket With Neon	A6-10 32A Switch Socket With Neon
				
A6-11 5 pin MF Switch Socket With Neon	A6-12 13A Switch Socket With Neon	A6-13 13A Switch Socket With Neon+2USB	A6-14 13A Switch Socket With Neon+USB+ Type-C	A6-15 5 pin MF Switch Socket With Neon+2USB
				
A6-16 5 pin MF Switch Socket With Neon+USB+ Type-C	A6-17 13A Socket	A6-18 Four Pole Socket	A6-19 5 pin MF Socket	A6-20 25A switch with neon
				
A6-21 45A switch with neon	A6-22 20A switch with neon	A6-23 45A switch with neon	A6-24 Germany socket	A6-25 French socket
				
A6-26 Europe socket	A6-27 Satellite Socket	A6-28 TV Socket	A6-29 TEL Socket	A6-30 Computer Socket

				
A6-31 TV+ TEL Socket	A6-32 Satellite+Computer Socket	A6-33 Double Computer Socket	A6-34 TV+Computer Socket	A6-35 Satellite+TV Socket
				
A6-36 Double TV Socket	A6-37 Dimmer Switch	A6-38 Speed Control Switch	A6-39 Human Body Sensor Switch	A6-40 25A Junction Box
				
A6-41 45A Junction Box	A6-42 86 Blank Plate	A6-43 Double 13A Switch Socket With Neon	A6-44 Double 13A Switch Socket With Neon+2USB	A6-45 Double 13A Switch Socket With Neon+USB+ Type-C
				
A6-46 Double 13A Socket	A6-47 Double MF Switch Socket With Neon	A6-48 Double MF Switch Socket With Neon+2USB	A6-49 Double MF Switch Socket With Neon+USB+ Type-C	A6-50 Cooker Unit
				
A6-51 Double 5 pin MF Switch Socket With Neon	A6-52 Double 5 pin MF Switch Socket With Neon+2USB	A6-53 Double 5 pin MF Switch Socket With Neon+USB+ Type-C	A6-54 146 Blank Plate	

Economical series



German Quality

THE PERFECT COMBINATION OF
QUALITY AND VALUE




KAREEMA

The configuration is flexible and vivid, and the ingenious combination of practicality and art shines with extraordinary charm in the flow of time.



ECO-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch



ECO-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch




ECO-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



ECO-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



ECO-05
Doorbell Switch




ECO-06
MF Switch Socket
With Neon




ECO-07
MF Switch Socket
With Neon+2USB




ECO-08
MF Switch Socket
With Neon+USB+ Type-C



ECO-09
15A Switch Socket With Neon
ECO-10
32A Switch Socket With Neon



ECO-11
5 pin MF Switch Socket
With Neon



ECO-12
13A Switch Socket
With Neon



ECO-13
13A Switch Socket
With Neon+2USB



ECO-14
13A Switch Socket
With Neon+USB+ Type-C



ECO-15
5 pin MF Switch Socket
With Neon+2USB



ECO-16
5 pin MF Switch Socket
With Neon+USB+ Type-C



ECO-17
13A Socket



ECO-18
Four Pole Socket



ECO-19
5 pin MF Socket



ECO-20
25A switch with neon



ECO-21
45A switch with neon



ECO-22
20A switch with neon
ECO-23
45A switch with neon



ECO-24
Germany socket



ECO-25
French socket



ECO-26
Europe socket



ECO-27
Satellite Socket



ECO-28
TV Socket



ECO-29
TEL Socket
ECO-30
Computer Socket



ECO-31
TV+ TEL Socket
ECO-32
Satellite+Computer Socket



ECO-33
Double Computer Socket
ECO-34
TV+Computer Socket



ECO-35
Satellite+TV Socket
ECO-36
Double TV Socket



ECO-37
Dimmer Switch
ECO-38
Speed Control Switch



ECO-39
Human Body Sensor
Switch




ECO-40
25A Junction Box




ECO-41
45A Junction Box




ECO-42
86 Blank Plate




ECO-43
Double 13A Switch Socket
With Neon




ECO-44
Double 13A Switch Socket
With Neon+2USB




ECO-45
Double 13A Switch Socket
With Neon+USB+ Type-C




ECO-46
Double 13A Socket




ECO-47
Double MF Switch Socket
With Neon




ECO-48
Double MF Switch Socket
With Neon+2USB




ECO-49
Double MF Switch Socket
With Neon+USB+ Type-C




ECO-50
Cooker Unit




ECO-51
Double 5 pin MF Switch Socket
With Neon



ECO-52
Double 5 pin MF Switch Socket
With Neon+2USB



ECO-53
Double 5 pin MF Switch Socket
With Neon+USB+ Type-C



ECO-54
146 Blank Plate

B1|series



Ultra-thin

Unique large board design, simple and flexible.
The perfect golden ratio without losing the sense of technology. Beneath the fashionable appearance,
It is gorgeous and beautiful. The interior exudes the charm of warm elements.

□ White □ Gold ■ Gray ■ Black

6.5mm



KAREEMA

The configuration is flexible and vivid, and the ingenious combination of practicality and art shines with extraordinary charm in the flow of time.



B1-01
1 Gang 1 Way Switch
1 Gang 2 Way Switch




B1-02
2 Gang 1 Way Switch
2 Gang 2 Way Switch



B1-03
3 Gang 1 Way Switch
3 Gang 2 Way Switch



B1-04
4 Gang 1 Way Switch
4 Gang 2 Way Switch



B1-05
Doorbell Switch



B1-06
MF Switch Socket
With Neon



B1-07
MF Switch Socket
With Neon+2USB



B1-08
MF Switch Socket
With Neon+USB+ Type-C



B1-09
15A Switch Socket With Neon
B1-10
32A Switch Socket With Neon



B1-11
5 pin MF Switch Socket
With Neon



B1-12
13A Switch Socket
With Neon



B1-13
13A Switch Socket
With Neon+2USB



B1-14
13A Switch Socket
With Neon+USB+ Type-C



B1-15
5 pin MF Switch Socket
With Neon+2USB



B1-16
5 pin MF Switch Socket
With Neon+USB+ Type-C



B1-17
13A Socket



B1-18
Four Pole Socket



B1-19
5 pin MF Socket



B1-20
25A switch with neon



B1-21
45A switch with neon



B1-22
20A switch with neon
B1-23
45A switch with neon



B1-24
Germany socket




B1-25
French socket



B1-26
Europe socket



B1-27
Satellite Socket



B1-28
TV Socket




B1-29
TEL Socket
B1-30
Computer Socket




B1-31
TV+ TEL Socket
B1-32
Satellite+Computer Socket



B1-33
Double Computer Socket
B1-34
TV+ Computer Socket




B1-35
Satellite+TV Socket
B1-36
Double TV Socket




B1-37
Dimmer Switch
B1-38
Speed Control Switch




B1-39
Human Body Sensor
Switch



B1-40
25A Junction Box



B1-41
45A Junction Box



B1-42
86 Blank Plate




B1-43
Double 13A Switch Socket
With Neon



B1-44
Double 13A Switch Socket
With Neon+2USB



B1-45
Double 13A Switch Socket
With Neon+USB+ Type-C



B1-46
Double 13A Socket




B1-47
Double MF Switch Socket
With Neon



B1-48
Double MF Switch Socket
With Neon+2USB



B1-49
Double MF Switch Socket
With Neon+USB+ Type-C




B1-50
Cooker Unit




B1-51
Double 5 pin MF Switch Socket
With Neon




B1-52
Double 5 pin MF Switch Socket
With Neon+2USB



B1-53
Double 5 pin MF Switch Socket
With Neon+USB+ Type-C



B1-54
146 Blank Plate



B1-01 1 Gang 1 Way Switch
1 Gang 2 Way Switch

B1-02 2 Gang 1 Way Switch
2 Gang 2 Way Switch

B1-03 3 Gang 1 Way Switch
3 Gang 2 Way Switch

B1-04 4 Gang 1 Way Switch
4 Gang 2 Way Switch

B1-05 Doorbell Switch



B1-06 MF Switch Socket
With Neon

B1-07 MF Switch Socket
With Neon+2USB

B1-08 MF Switch Socket
With Neon+USB+ Type-C

B1-09 15A Switch Socket With Neon
B1-10 32A Switch Socket With Neon

B1-11 5 pin MF Switch Socket
With Neon



B1-12 13A Switch Socket
With Neon

B1-13 13A Switch Socket
With Neon+2USB

B1-14 13A Switch Socket
With Neon+USB+ Type-C

B1-15 5 pin MF Switch Socket
With Neon+2USB

B1-16 5 pin MF Switch Socket
With Neon+USB+ Type-C



B1-17 13A Socket

B1-18 Four Pole Socket

B1-19 5 pin MF Socket

B1-20 25A switch with neon

B1-21 45A switch with neon




B1-22 20A switch with neon
B1-23 45A switch with neon

B1-24 Germany socket

B1-25 French socket

B1-26 Europe socket

B1-27 Satellite Socket



B1-28 TV Socket

B1-29 TEL Socket
B1-30 Computer Socket

B1-31 TV+ TEL Socket
B1-32 Satellite+Computer Socket

B1-33 Double Computer Socket
B1-34 TV+Computer Socket

B1-35 Satellite+TV Socket
B1-36 Double TV Socket




B1-37 Dimmer Switch
B1-38 Speed Control Switch

B1-39 Human Body Sensor
Switch

B1-40 25A Junction Box

B1-41 45A Junction Box

B1-42 86 Blank Plate




B1-43 Double 13A Switch Socket
With Neon

B1-44 Double 13A Switch Socket
With Neon+2USB

B1-45 Double 13A Switch Socket
With Neon+USB+ Type-C

B1-46 Double 13A Socket




B1-47 Double MF Switch Socket
With Neon

B1-48 Double MF Switch Socket
With Neon+2USB

B1-49 Double MF Switch Socket
With Neon+USB+ Type-C

B1-50 Cooker Unit



B1-51 Double 5 pin MF Switch Socket
With Neon

B1-52 Double 5 pin MF Switch Socket
With Neon+2USB

B1-53 Double 5 pin MF Switch Socket
With Neon+USB+ Type-C

B1-54 146 Blank Plate

Big rocker switch



Ultra-thin

Unique large board design, simple and flexible.
The perfect golden ratio without losing the sense of technology, Beneath the fashionable appearance, it is gorgeous and beautiful.
The interior exudes the charm of warm elements.

□ White ■ Gold ■ Gray ■ Black




B1-55
MF Switch Socket
With Neon



B1-56
13A Switch Socket
With Neon



B1-57
5 pin MF Switch Socket
With Neon




B1-58
20A switch with neon
B1-59
45A switch with neon



B1-55
MF Switch Socket
With Neon



B1-56
13A Switch Socket
With Neon



B1-57
5 pin MF Switch Socket
With Neon



B1-58
20A switch with neon
B1-59
45A switch with neon



B1-55
MF Switch Socket
With Neon



B1-56
13A Switch Socket
With Neon



B1-57
5 pin MF Switch Socket
With Neon



B1-58
20A switch with neon
B1-59
45A switch with neon



B1-55
MF Switch Socket
With Neon



B1-56
13A Switch Socket
With Neon



B1-57
5 pin MF Switch Socket
With Neon



B1-58
20A switch with neon
B1-59
45A switch with neon